
GENERAL ELECTRIC 973E506
VALVE, GAS STOP/RATIO CONT ASSY
SECTION C-3 (L-2)
SECTION C-8 (D-8)
VIEW C-10 (B-10)
SECTION B-12 (B-7)
SECTION C-12 (A-8)
VIEW E-11 (C-9)
SECTION H-12 (A-7)
SECTION M-3 (E-10)
VIEW L-11 (A-9)
GROUP 9 ONLY
BASIC VALVE ASSY ONLY
CALCULATED WT 2800 LBS
NOTES:
1. SHRINK VALVE SEATS PART NO.17 INTO BODY PART NO.87 AND PART NO. 32.
2. ASSEMBLE PACKING RINGS PART NO.12 WITH "V" JOINTS AS SHOWN. CARE MUST BE TAKEN NOT TO NICK OR CUT PACKING. PACKING MUST HAVE A SLIGHT INTERFERENCE AT LIP AND FREEDOM AT HEEL ON SHAFT AND IN BORE. ASSEMBLE PACKING IN BORE BEFORE INSERTING SHAFTS.
3. SHRINK BUSHINGS PART NO'S 56 AND 62 INTO BODY PART NO.87 AND 32. CHECK BUSHING BORES AFTER ASSEMBLY TO BE .1375 +.000 -.0005 HONE IF NECESSARY TO MEET THIS DIMENSION.
4. TAPE ALL OPENINGS INCLUDING DUMP VALVE AREA TO PREVENT FOREIGN MATTER FROM GETTING INTO VALVE DURING STORAGE AND TRANSPORTATION.
5. ALL EXTERNAL SURFACES EXCEPT WORKING SURFACES TO BE CLEANED PER ITEM 3, TYPE 1 AND 3, AND PAINTED PER ITEM 2.
6. .251 +.003 -.000 Ø DRILL FOR .25 SPRING DOWEL. LOCATE FROM PILOT IN GUIDE ARM, ARM HEIGHT TO BE AT DIMENSION INDICATED.
7. CONNECT LYDT'S PER ITEM 8. COIL THESE LEADS IN JUNCTION BOX. DO NOT CUT.
8. TORQUE ALL BOLTS PER ITEM 6.
9. WRAP .005 SHIM STOCK AROUND STEM RELIEF OF PART NO. 20 TO PREVENT DAMAGING PACKING PART NO.12 AND PART NO. 8 WHEN INSERTING OR REMOVING IT.
10. WITH PISTON IN HYDRAULIC CYLINDER PART NO. 49 AGAINST CYLINDER HEAD, PISTON ROD FULL EXTENDED, MEASURE AND RECORD CLEARANCE BETWEEN END OF PISTON ROD AND S/R VALVE STEM, PART 20 SUBASSEMBLY. MOVE PISTON ROD UP TO INCREASE CLEARANCE BY .09 ± .03 AND ASSEMBLE SPLIT YOKE NUT PART NO. 52, ENGAGING MATING THREADS. BOLT TOGETHER AND LOCK, THEN DRILL FOR DOWEL PART NO. 69.
11. ENGRAVE DRAWING NO., GROUP NO. AND SERIAL NO. ON NAMEPLATE PART NO. 34, PRIOR TO INSTALLATION TO BODY AND FLG GCV.
12. TEST PER ITEM 3.
13. SEE ITEM 6 FOR ELEC CONN. DIAGRAM.
14. FOR REFERENCE SPRING DATA WHICH MAY BE USED IN TEST SEE DRAWING ZONE M-11.
15. ALL WELDS TO BE PER ITEM 7, FIG F1, COL AB, CLASS III.
16. SEE ARI ITEM 0432, FUEL GAS SCHEMATIC PIPING DIAGRAM, FOR GAS VALVE ASSEMBLY SCHEMATIC.
17. ASSEMBLE ALL TUBING AND CHAMFER TUBE I.D.'S TO REMOVE CUTTER BURR PER ITEM 4.
18. INSTALL BREATHER PROVIDED WITH JUNCTION BOX INTO .375 NPT HOLE IN BOTTOM OF BOX.
19. REFER TO ML ITEM 0541 FOR SERVO ARR, GAS STOP/RATIO & CONTROL VALVE.
20. MOUNTING PROVISIONS FOR JB52, REF ML ITEM 0557 PRESSURE TRANSDUCER ARR.
STOP/RATIO VALVE AND PILOT
SPRING DATA
STOP/RATIO VALVE
CONTROL VALVE
5.00 X 1.00
INNER VLV .590 MAX STROKE .370 MIN
INNER VALVE CLOSED 2.34-3 MAX 1945 MIN
VALVE CLOSED 1320 MAX 1080 MIN
VALVE OPEN 3021 MAX 2388 MIN
PROPRIETARY INFORMATION
DO NOT RUN TUBING UNDER FILTER BOWL
SEE ITEM 19
SEE ITEM 21